

D3 Airow Post Mount System

System weight
3kg



What You'll Receive



A - Bracket x 2



B - Banding Straps x 4



C - Banner Arm x 2

D3 Airow Post Mount System

- 1) Install the top **bracket (A)** first, ensuring that the “top” designation is facing up. Place the bracket against the post in its intended location using either a shock cord with hooks or gripper tape to temporarily hold it in place.
- 2) Attach two **banding straps (B)** around the bracket to hold it in place on the column/post - one banding strap at the top of the bracket and one at the bottom.
- 3) Tighten the banding straps until they are tensioned correctly, and they are parallel to the edge of the bracket.
- 4) Remove the hitch pin and slide the **banner arm (C)** into the bracket. Important, the banner arms are canted to provide tension, always ensure the top arm is looking upwards.
- 5) Replace the hitch pin.
- 6) Position the banner arm in the centre of the bracket and tighten the arm in place using an allen key on the four stainless steel screws on the front of the bracket. Do not overtighten at this stage, as you may need to make minor adjustments once the bottom arm and banner and bottom arm is installed.
- 7) Slide the banner on to the top arm so that it sits very close to the bracket, ensuring the eyeletted side of the banner is closest to the post.
- 8) Secure the banner with cable ties through the eyelet and the small hole on the bracket.
- 9) Allow the banner to drop to mark out the location of the bottom bracket. Repeat steps 1 to 3 to Mount the bottom bracket on to the post, ensuring that the bottom edge of the bracket is approximately 60mm lower than the bottom edge of the banner.
- 10) Slide the banner onto the bottom arm and then install the arm into the bracket following steps 4 – 6, this time ensuring that the arm has a downward cant.
- 11) Finally, slightly adjust the location of the arms within the brackets to create the correct tension in the banner. Once satisfied, using an allen key fully tighten the four screws on the front of the top bracket followed by the four screws on the bottom bracket.

Need More Help?

Our team are only a phone call away and more than happy to answer any questions you might have.

Alternatively, you can visit [bannerbox.co.uk/guides](https://www.bannerbox.co.uk/guides) for more detailed guidance.