

Wall Mount System - Face Fix

System weight
30kg



What You'll Receive



A - Closed Wall Bracket x 2



B - Open Wall Bracket x 2



C - Top Arm



D - Tensioner Arm



E - Tensioners x 2



F - Bottom Arm

Wall Mount System - Face Fix

- 1) Identify the final position where the system will be located. Starting at the top, hold a **closed wall bracket (A)** against the wall and mark the fixing points.
- 2) Remove the bracket from the wall and drill into the marked locations. Once drilling is completed, install raw bolts.
- 3) Holding the bracket against the wall, install the fixings and tighten until the bracket sits flush against the wall.
- 4) Install an **open wall bracket (B)** onto one end of the **top arm (C)** and secure using the securing bolt.
- 5) Install the opposite end of the top arm into the closed wall bracket already installed on the wall and secure using the securing bolt.
- 6) Using a spirit level for accuracy, adjust the height of the open bracket on the top arm is horizontal and mark out fixing locations.
- 7) Remove the open bracket from the top pole and drill into the marked locations. Once drilling is completed, install raw bolts.
- 8) Insert the banner onto the top pole and then reinstall the open bracket onto the top pole. Return the open bracket back to the wall and install the fixings, tighten until the bracket sits flush against the wall. Now you have the top brackets and arm installed, allow the banner to drop.
- 9) Thread the **tensioner arm (D)** through the bottom pocket in the banner, ensuring the D loops sit outside of the banner.
- 10) Attach one end of the **tensioners (E)** onto both D-loops on the tensioner pole.
- 11) Attach the remaining closed and open wall brackets to each end of the **bottom arm (F)** and secure using the securing bolts. Attach open end of the tensioners onto the two D-loops on the bottom arm.
- 12) Extend the tensioners, allowing you scope to tighten the banner once installed. Hold the brackets against the wall and mark out the drilling points.
- 13) Remove the brackets from the wall and drill into the marked locations. Once drilling is complete, install raw bolts.
- 14) Holding the brackets against the wall, install the fixings and tighten until the brackets sit flush against the wall.
- 15) To complete installation, adjust tensioners on both sides ensuring the banner is under correct tension and perfectly aligned.

Need More Help?

Our team are only a phone call away and more than happy to answer any questions you might have.

Alternatively, you can visit [bannerbox.co.uk/guides](https://www.bannerbox.co.uk/guides) for more detailed guidance.